

J-32-5 22
McKay Oil Corp.
Inexco ST. #2

- * Set 30 sk cement plug @ surface.
- * Set tubing @ 1058', set 50 sk cement plug. TAG
- * Place 100' cement Plug 50' in + 50' out 4 1/2" csg stub. TAG
- * Freepoint + cut 4 1/2" csg.
- * Circulate brine gel to surface.
- * Run + set CIBP @ 2853' w/ 35' cement.

/// CIBP-2853' w/ 35' cement.

≠ T Perf. 2853'-60'

8 5/8" - 1008'
circ,

4 1/2" - 4300'
w/ 475 sk
Cal. Pac - 2215'