## EXHIBIT "A"

SUBSEQUENT REPORT OF PLUG AND ABANDONMENT CAMEL STATE #3 WELL

- 3/27/89 1.Set CIBP at 6110. Spotted 25 sacks of cement on top of plug at 6110'. 2.Spotted 25 sacks at 5299', top of Wolfcamp. 3.Spotted 25 sacks at 4600', top of ABO.
- 3/28/89 l.Ran free-point, found pipe stack at 3813', free at 3800'. Shot off casing at 3800', recovered 3800' of 5½" casing.
- 3/29/89 1.Ran tubing to 3864', spotted 35 sacks at 3864', with 3% CaCl. Waited on cement 2 hours. Tagged cement at 3760', stub plug.
  2.Pulled up to 2500' and spotted 35 sacks, top of Glorieta.
  3.Pulled up to 1068', shoe of 8 5/8", and spotted 35 sacks with 3% CaCl. Waited on Cement overnight.
- \$\mathcal{J}/30/39\$ 1.Ran tubing and tagged at 1036'. Spotted 20 sacks at 1036'. Waited on cement 1 hour and tagged at 960' with sandline. 2.Spotted 10 sacks at surface.

Note: Salt Gel between plugs.

P & A Completed.
Witnessed by Mike Williams and Mike Stubblefield.