

9000' from surface in old casing string. Swab well. Recover drilling mud. Release rig.

1/8/98 thru 1/9/98

- Rig up pulling unit. Swab well. Recover 100% drilling mud changing to oil cut drilling mud changing to 100% oil. Hook up to tanks. Release rig.