

UNITED STATES DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
Artesia, New Mexico  
SUBMITTER'S LICENSE  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-069817

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

APR 04 '88

2. NAME OF OPERATOR

McClellan Oil Corporation

O. C. D.

3. ADDRESS OF OPERATOR

P.O. Drawer 730, Roswell, N.M. 88202

ARTESIA, OFFICE

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

660 FSL & 1650 FWL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Patrick Fed.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Double L Queen Assoc.

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 12-T15S-R29E

12. COUNTY OR PARISH 13. STATE

Chaves

N.M.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CR, etc.)

3908' G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

3/24 Pursuant to our phone conversation we propose to:

- (1) Pull tubing and Re-run tubing w/bit & scraper.
- (2) Drill out salt and gyp plugs from 1900 to 1995.
- (3) Circulate hole w/water to clean hole.
- (4) Run packer to  $\pm$  1930 feet. Load tubing-casing annulus. Test Casing Annulus to 500 psi. (Note: BLM will be notified 24 hrs. in advance).
- (5) Reacidize perfs w/500 gals 15% MCA acid.
- (6) Put on pump to pump back load.

MAR 25 8 36 AM '88  
BUREAU OF LAND MGT  
ROSWELL RESOURCE AREA

RECEIVED

18. I hereby certify that the foregoing is true and correct

SIGNED

*Paul Kaye*

TITLE Operations Manager

DATE 3/24/88

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED  
PETER W. CHESTER

MAR 29 1988

BUREAU OF LAND MANAGEMENT  
ROSWELL RESOURCE AREA

\*See Instructions on Reverse Side