

COMPANY <i>Delmar W. Berry</i>	PROPERTY NAME <i>State A</i>	WELL NO. <i>1</i>
-----------------------------------	---------------------------------	----------------------

DATE	LOCATION (ULSTR) <i>2-15-29 ut. K</i>	FOOTAGE <i>1980 ES + WL</i>
------	--	--------------------------------

API NO. <i>30-005-60282</i>	POOL <i>Double L Queen</i>
--------------------------------	-------------------------------

1. Spot a 40 sx plug & 1913' abc + tag
2. Spot a 25 sx plug & 850'
3. Perforate @ 250 & squeeze cement to surface on backside at 4 1/2 csg. When cmt circulates close bradenhead valve & pump 4 1/2 csg full to surface.
4. Place mud between pluggs.
5. Set P & A marker
6. Cut anchors, clean & level location.

CASING RECORD:

8 5/8" @ 200' w/100 sx 10 1/4" hole
4 1/2" @ 1982 w/200 sx 7 7/8" hole

After

8 5/8" @ 200'
Perte 250
TX 345
BX 835

Est TOC

1431'

TOP
Queen 1908
Perte 1913'
4 1/2" @ 1982'

