

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPER OR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

JUN 11 1976

Form C-103
Supersedes Old
C-102 and C-101
Effective 1-1-65

O. C. C.

ARTESIA, OFFICE

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

5a. Indicate Type of Well State XX Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5999
7. Unit Agreement Name
8. Name of Lease Name Dunken Dome Unit
9. Well No. 1
10. Field, Pool, or Well Unit Wildcat
12. County Chaves

1. <input type="checkbox"/> OIL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Plugged & Abandoned
2. Name of Operator Yates Petroleum Corporation
3. Address of Operator 207 So. 4th Street - Artesia, NM 88210
4. Location of Well UNIT LETTER K 1700 FEET FROM THE West LINE AND 1980 FEET FROM THE South LINE, SECTION 7 TOWNSHIP 17S RANGE 18E N.M.P.M.

15. Elevation (Show whether DF, RT, GP, etc.) 5392 GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:	
REMEDIAL WORK <input type="checkbox"/>	ENTERING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated work) SEE RULE 1103.

TD 5826'; PBTB 3373' - Verbal approval was given by Mr. W. A. Gressett, Supervisor, District # II with the Oil Conservation Commission and well was plugged as follows:

Set CIBP at 3100' and dumped 30' of cement on top, cut off casing at 2791' and laid down recovery.

Plugs: - 50 sacks across stub at 2800-2700'
50 sacks 2250-2150'
50 sacks 1250-1150'
10 sacks at surface w/dry hole marker

Heavy mud was placed between each plug.

When the location is ready for inspection we will notify you.

*posted pda
IDZ 6-11-76*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Christine Tomlinson TITLE Geol. Secty

6-10-76

APPROVED BY Alan Morris

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY: