

TOPS

T Salt	~ 450
B Salt	~ 1000
Yates	1184
7 Rivers	1747
Green	1932

← 60' Surface Plg.

← 400' TAL Shop Plug.

← 1100'. TAC Base Set *
Plus *

← 1834' 70.

± T. Pert. 1934'. 116.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated **up**.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of **all** casing string(s) in the correct footage or sacks required, **if no cement exists**.
- * Plugs to be tagged will be indicated.

8 7/8" csy
350.
circ.

4 1/2" x 5 1/2"
1976' w/ 350 x 500 cement,
Circ.