

Operator McQuinn, L.C.
 Well SR LG Unit #5
 Unit C Section 35 Township 17 Range 27
 API # 30-015-00611

TOPS

Heater ~ 500
Blowers ~ 650
Quinn ~ 850
Grayburn ~ 1275

← Surface plug 0' to 60'
 Perf & squeeze

← plug 500'
 Perf & squeeze

886' ← TOC calc @ 50%

7" @ 1290'
 w/ 50 SXS.
 8" hole

← plug 1290' TAG

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

MLB