

Operator Pronghun R. Corp.  
 Well Shute 'A' #2  
 Unit B Section 36 Township 17 Range 23  
 API # 30-013-20020

TOPS

Yates 375'

← 60' Surface Plug.

- \* Contact OCD 24 hrs. prior to any work done.
- \* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- \* Install dry hole marker as per Rule 202.B.2
- \* Plugs are to be set from point indicated up.
- \* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- \* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- \* Surface plug will be from 0' - 60'
- \* Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- \* Plugs to be tagged will be indicated.

(A). TOC - 423'

← 480' Cement Plug inside & outside 5" csg. TAG

5" @ 485'  
 TOC

MS