

Operator Pronghorn Mngt. Corp.
 Well Acres #2
 Unit F Section 36 Township 17 Range 27
 API # 30-015-00663

TOPS

Gates ~ 375'
Thiwers ~ 480'

← 0-60' Plug Surf.

313' Calc TOC

← Plug 375'

← Plug 445' TAG

7" @ 445'
 30 SXS

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

[Handwritten signature]