

Operator McDonald, L.C.
 Well SRLG Unit #23
 Unit 5 Section 36 Township 17 Range 27
 API # 30-015-01221

TOPS

Bowlers 2716
Shoe 2000
Shayb 1350

← Surf Plug

← plug 7'6"

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

?
 2 1/4" @ 496
 5 SXS

← Shoes Plug 946'-1046' Tag

← Est Toc 1300'

7" @ 1520'
 5 C SXS.

← Plug 1520'-1420' Tag

18