

COPIES RECEIVED	3
TRIBUTION	
FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

APR 5 - 1974

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-5313
7. Unit Agreement Name Empire Abo Unit "H"
8. Farm or Lease Name
9. Well No. 19
10. Field and Pool, or Wildcat Empire Abo
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator Atlantic Richfield Company
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER <u>0</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>36</u> TOWNSHIP <u>17S</u> RANGE <u>27E</u> NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
3652' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Present perforations 5648-5800'.

Propose to perforate lower, acidize & treat in the following manner -

Clean out fill to 5919' PBD.

Perforate 5832, 5834, 5837, 5839, 5844, 5846, 5860, 5862, 5870, 5874, 5876, 5878, 5880' w/1 JSPF.

Set treating packer between 5810-5820'.

Treat w/3000 gals 15% HCl-LSTNE acid & ball sealers.

Pull treating pkr and set production packer between 5810-5820'.

Swab well, test and return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. J. Berman TITLE Dist. Drlg. Supv. DATE 4/1/74

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE APR 5 1974

CONDITIONS OF APPROVAL, IF ANY: