

Operator Kersey + Co
 Well ASU "A" #
 Unit M Section 2 Township 17S Range 28E
 API # 30-015-01306

TOPS

 T. Salt 320'
 B. Salt 445'
 Glorieta _____
 Bone Sp. _____
 Abo _____
 Wolfcamp _____
 Morrow _____
 Devonian _____
 Fusselman _____
 Other _____

← 60' Surface Plug.

← 320' TAG

← 545' TAG

← 1544' TAG

= Perfs 1644'-64'

2 7/8" csg @ 1690' w/ 312 x 15 cmT. Circ. To Surface.
 2 1/2" 6" Hole

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.