

Operator Premier Drilling
 Well Hassie #3
 Unit E Section 18 Township 17 Range 28
 API # 30-018-01422

TOPS

No TOPS

← 60' Surface Plug.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of **all** casing string(s) in the correct footage or sacks required, if no **cement exists.**
- * Plugs to be tagged will be indicated.

21. To C. 401'

7" @ 460'

2.5" @ 480'

Est. 10" @ 400'

← 351' Cement Plug Inside + Outside 7" casing. TOPS

VMS