

OIL CONSERVATION DIVISION

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	<input checked="" type="checkbox"/>

RECEIVED BY P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

NOV 7 1985

O. C. D.

ARTESIA O-517E

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
B-1969

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER: Injection	7. Unit Agreement Name Brent Red Lake Unit
2. Name of Operator Kersey & Co, Red Lake Unit	8. Farm or Lease Name Wetch Sand Mt. Tr. 11
3. Address of Operator P. O. Box 316, Artesia, N.M.	9. Well No. 13
4. Location of Well UNIT LETTER M 330 FEET FROM THE West LINE AND 330 FEET FROM THE South LINE, SECTION 21 TOWNSHIP 17S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Red Lake
15. Elevation (Show whether DF, RT, GR, etc.) 3595' GL	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Put cement plug 1600-1700'  
Tag plug 1475'
- Put cement plug 900-1000'  
Tag plug 899'
- Put cement plug 388-488'  
Tag plug 289'
- Put cement plug at Surface.
- Set 4" Pipe Marker at Surface.

Post FD-2  
11-15-85  
P+A

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Narvel Kersey TITLE co-owner DATE Nov. 7, 1985

APPROVED BY Danell Moore TITLE Geologist DATE 4/10/86

CONDITIONS OF APPROVAL, IF ANY: