

Operator Smith & Mars, Inc
 Well RLS-1132
 Unit E Section 21 Township 17 Range 28
 API # 30-015-01492

TOPS

Yates ~ 500'
7 Meters ~ 725'
Bowers ~ 1100'
Queen ~ 1300'

← Plug 60'-0 Surface

— Plug 500' TAG

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

5 5/8" c 1929'

— Plug 1529' TAG

T.D 1979'

[Handwritten signature]