

Operator
Well
Unit
API #

Smith, Manns, Inc.
RLSU #31
E Section 21 Township 17 Range 28
30-015-01493

TOPS

Yates ~ 500'
Trivers ~ 725'
Bowers ~ 1100'
Queen ~ 1300'

Est. TOC 350'
calc @ 50%

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

8 1/4" @ 533'
50 SXS
Est 10 1/2" hole

Shoe plug
483' to 583'
TAG

1238' ← TOC calc @ 50%

7" @ 1715'
100 SXS
Est. 8 5/8" hole

1715' TAG

TD 2023'

MLB