

## TOPS

|           |   |      |
|-----------|---|------|
| Yates     | ~ | 330  |
| T. Rivers | ~ | 620  |
| Powers    | ~ | 960  |
| Green     | ~ | 1200 |
| Laughing  | ~ | 1500 |
| Auto      | ~ | 1960 |

← shoe Plug 452' - ~~452'~~ TAG.

← Shoe Play TAG.  
1605-1505

← P122

← Play 1818' TAG

- \* Contact OCD 24 hrs. prior to any work done.
- \* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- \* Install dry hole marker as per Rule 202.B.2
- \* Plugs are to be set from point indicated up.
- \* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- \* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- \* Surface plug will be from 0' - 60'
- \* Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- \* Plugs to be tagged will be indicated.

