I. I	~, _\ 51
Submit 3 Copies To Appropriate District State of New Mexico	Form C-1
Office Energy Minerals and Natural Resour	rces Revised March 25, 19
District I Energy, Witherars and Waterar Resources 1625 N. French Dr., Hobbs, NM 88240	WELL API NO.
District II OIL CONSERVATION DIVISIO	ON 30-015-01721
STI South Fust, Allesia, INM 66210	5. Indicate Type of Lease
District III2040 South Pacheco1000 Rio Brazos Rd., Aztec, NM 87410Santa Fe, NM 87505	STATE STATE
District IV 2040 South Pacheco, Santa Fe, NM 87505	6. State Oil & Gas Lease No. B2071
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Nam
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	Carper Levers
1. Type of Well:	
Oil Well 🖾 Gas Well 🗌 Other	8. Well No. 4
2. Name of Operator Vintage Drilling LLC	
3. Address of Operator	9. Pool name or Wildcat
P.O. Box 158 Loco Hills, NM 88255	ARTESIA QNGRSA
4. Well Location	
	and 2310 feet from the West 1
Unit Letter <u>K</u> : <u>1650</u> feet from the <u>South</u> line	$\frac{2310}{100}$ rect nom the <u>west</u>
Section 34 Township 17S Range	28E NMPM Eddy County
10. Elevation (Show whether DR, RKB, R	
11. Check Appropriate Box to Indicate Nature of I	
	ENCE DRILLING OPNS. PLUG AND ABANDONMENT ABANDONMENT TEST AND I
COMPLETION	T JOB
	ails, and give pertinent dates, including estimated of
OTHER: OTHER: OTHER: OTHER: OTHER:	ails, and give pertinent dates, including estimated of
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure	ails, and give pertinent dates, including estimated on the set of
OTHER: Image: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out	ails, and give pertinent dates, including estimated on the set of
OTHER: Image: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & ou Tag to check plug. Circulate hole w/brine iel	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: Image: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & ou Tag to check plug. Circulate hole w/brine iel	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: Image: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug.	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: Image: OTHER: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & ou Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel.	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & ou Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface	ails, and give pertinent dates, including estimated ons: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: Image: OTHER: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & ou Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel.	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker.	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & ou Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker.	ails, and give pertinent dates, including estimated on ns: Attach wellbore diagram of proposed completing the state of Casing.
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker. Will start work as soon as we can get a plugging unit.	ails, and give pertinent dates, including estimated on some set of the set of
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker.	ails, and give pertinent dates, including estimated on some set of the set of
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & ou Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker. Will start work as soon as we can get a plugging unit. Thereby certify that the information above is true and complete to the best of marker.	ails, and give pertinent dates, including estimated on some set of the set of
OTHER: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker. Will start work as soon as we can get a plugging unit. I hereby certify that the information above is true and complete to the best of my SIGNATURE	ails, and give pertinent dates, including estimated on s: Attach wellbore diagram of proposed completion the side of Casing.
OTHER: □ OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker. Will start work as soon as we can get a plugging unit. I hereby certify that the information above is true and complete to the best of my SIGNATURE Type or print name Marie Durham	ails, and give pertinent dates, including estimated on s: Attach wellbore diagram of proposed completion the side of Casing.
OTHER: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent deta of starting any proposed work). SEE RULE 1103. For Multiple Completion or recompilation. Plugging Procedure Perforate @ 1300', set packer @ appx 1200' squeeze 100' plug inside & out Tag to check plug. Circulate hole w/brine jel. Perforate @ 581', Set packer @ appx. 300' squeeze 100' plug inside & outs Tag to check plug. Circulate w/brine jel. Perforate @ 50' Circulate cement to surface Install dry hole marker. Will start work as soon as we can get a plugging unit. I hereby certify that the information above is true and complete to the best of my SIGNATURE	ails, and give pertinent dates, including estimated ons: Attach wellbore diagram of proposed completing the side of Casing. Side of Casing. y knowledge and belief. Secretary DATE01/21/01 Telephone No. 505-748-2941

•

Conditions	of approval,	if any: