

Operator Beach Exploration Inc

Well Brainard Fed #1

Unit 0 Section 20 Township 16 Range 29

API # 30-015-02761

TOPS

Yates 800

T. Salt 340

B. Salt 600

Glorieta _____

Bone Sp. _____

Abo _____

Wolfcamp _____

Morrow _____

Devonian _____

Fusselman _____

Other _____

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

← 60' Surface Plug

858
365'
CWC

← 315'-415' - Shoe Plug
TAG₂

← 800' - TAG

1026' ——— TOC

← 1800 - TAG

1810'
1866 — Perfs

5 1/2"
1884