

Operator C.E. LaRue 3 N. Murcy
Well Leonard #2
Unit N Section 36 Township 16 Range 29
API # 30-015-02821

TOPS

T. Salt 526
B. Salt 966
Yates 1125
Glorieta _____
Delaware _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

← 60' surface plug

← Shoe Plug 305' - 405' TAG

← 526' TAG

← 1100' TAG

2314' ——— TOC @ 50%
← 2500' TAG

2506' — Puts
2672'
5 1/2" 2695'