

Operator C.E. LaRue B.N. Murry
Well Leopard #7
Unit G Section 36 Township 16 Range 29
API # 30-015--02829

T. Salt 551 TOPS
B. Salt 988
Yates 1147
Glorieta _____
Delaware _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

← 60 Surface Plug

← Shoe Plug 295' - 395' TAG

← 1147' - TAG

2264' ——— TOC @ 50%

← 2500' - TAG

2512' ——— Top Ref

5 1/2"
2740'

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.