6-11-01
PRESSURE TEST WELL TO 1000# - POOH - RIH & SPOT 20 SXS @ 228' TO
SURFACE - POOH - RIG DOWN - CUT OFF WELLHEAD - INSTALL DRY HOLE
MARKER - LEVEL PIT & CELLAR - MOVE OUT

OCDREP1.DOC

