

ATTACHMENT A

RECEIVED
NOV 7 1961
O. C. C.
ARTESIA, OFFICE

We propose to drill and complete this well without setting surface casing using the following procedure.

1. Drill 6-3/4" or 6-1/4" hole to TD.
2. Set 2-7/8" oil string casing at TD.
3. Cement first stage from the bottom of the shoe back into the salt section using 300 sacks of 4% Gel cmt.
4. Run a small retrievable string of tubing outside the oil string casing to 500' and circulate cement to the surface of the ground using 250 sacks of 4% Gel cmt.
5. All available logs and information indicate no surface water in this area.
6. This method of completion would adequately protect any fresh water encountered.

2 cores in the Grayburg zone. 1 at 2900' and 1 at 3000'.
HOWCO method of cementing to be used.
Min. mud for samples.