

ATTACHMENT A

We propose to drill and complete this well without setting surface casing using the following procedure.

1. Drill 6-3/4" or 6-1/4" hole to TD.
2. Set 2-7/8" oil string casing at TD.
3. Cement first stage from the bottom of the shoe back into the salt section using 300 sacks of 4% Gel cmt.
4. Run a small retrieveable string of tubing outside the oil string casing to 500' and circulate cement to the surface of the ground using 250 sacks of 4% Gel cmt.
5. All available logs and information indicate no surface water in this area.
6. This method of completion would adequately protect any fresh water encountered.

2 cores in the Grayburg zone. 1 at 2900' and one at 3000'.
HOWCO method of cementing to be used.
Min. Mud for samples.

OIL CONSERVATION COMMISSION		
ARTESIA DISTRICT OFFICE		
No. Chapter (if any)		
Date		
	Time	
	Personnel	
DEPUTY	1	
LAND FL	1	
PROBATION OFFICE		
STATE LAND OFFICE	1	
U. S. G. S.	2	
TRANSPORTER		
FILE	1	✓
BUREAU OF MINES		