NEW MEXICO OIL CONSERVATION COMMISSION Santa Fe, New Mexico

MISCELLANEOUS NOTICES

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See addies in the Rules and Regulations of the Commission

		Indicate Nature of Notice by Check	ing Zeov
otice of Intention Change Plans		Notice of Intention to Temporarily Abandon Well	Notice of Intention to Drill Deeper
OTICE OF INTENTION OF PLUG WELL	x	Notice of Intention to Pluc Back	Notice of Intention to Set Liner
Iotide of Intention o Squeeze		Notice of Intention to Acidize	Notice of Intention to Shoot (Nitro)
Notice of Intention to Gun Perforate		Notice of Intention (Other)	Notice of Intention (Other)
DIL CONSERVATION COMP SANTA FE, NEW MEXICO	MISSION	P. O. Bex 352, Midland, TEIACO Inc.	Texas September 23, 195
		(* ****)	(
Gentlemen:			
Following is a Notice of It	ntention to do	certain work as described below at the	Well No. in Woman, West (Grayburg)
Lot /4 (Comp	eny or Operator) Lesse	Well Noin
	(FOLLOW	L DETAILS OF PROPOSED PL INSTRUCTIONS IN THE RULES	
. Cut and pull han spot 25 sx from . Spot 25 sx from . Spot 15 sx at su	t from 2 casing a 50' below 400' to rface in	7 INSTRUCTIONS IN THE RULES 8781 to 29781 inside $\frac{1}{12}$	off light OD casing.
cut and pull light. Spot 25 ax from Spot 25 ax from Spot 15 ax at su	t from 2 casing a 50' below 400' to rface in	instructions in the rules 878; to 2978; inside $\frac{1}{12}$; at 1870; w to 50; above top of cut 500; (ever surface casing side 8 5/8; OD casing.	off light OD casing.
2. Gut and pull high 3. Spot 25 sx from 4. Spot 25 sx from 5. Spot 15 sx at su 6. Install him marks	t from 2 casing a 50' below 400' to rface in	instructions in the rules 878; to 2978; inside $\frac{1}{12}$; at 1870; w to 50; above top of cut 500; (ever surface casing side 8 5/8; OD casing.	and regulations) casing. off light OD casing. seat).
2. Gut and pull high 3. Spot 25 sx from 4. Spot 25 sx from 5. Spot 15 sx at su 6. Install him marks	t from 2 casing a 50* belo 400* to rface in a extend	instructions in the rules 878; to 2978; inside $\frac{1}{12}$; at 1870; w to 50; above top of cut 500; (ever surface casing side 8 5/8; OD casing.	off light OD casing.
2. Cut and pull him 3. Spot 25 ax from 4. Spot 25 ax from 5. Spot 15 ax at su 6. Install he marks Approved	t from 2 casing a 50* belo 400* to rface in a extend	instructions in the rules 878; to 2978; inside $\frac{1}{12}$; at 1870; w to 50; above top of cut 500; (ever surface casing side 8 5/8; OD casing.	easing. off light OD casing. seat).
2. Cut and pull him. 3. Spot 25 ax from . 4. Spot 25 ax from . 5. Spot 15 ax at su . 6. Install him marks.	t from 2: casing: 50: belo 400: to rface in r extend	instructions in the rules 878; to 2978; inside $\frac{1}{12}$ at 1870; we to 50; above top of cut 500; (ever surface casing side 8 5/8; CD casing. ing h; above ground level.	easing. off light OD casing. seat).

SAND, STAT ÖATI Ü