Initial injection is to be through the nine authorized water injection wells, each of which is to be equipped with 2 3/8-inch cement- or plastic-lined tubing set in a packer. The packers shall be set approximately 50 feet above the uppermost perforation or in the case of open-hole completions, approximately 50 feet above the casing shoe. The casing-tubing actualus shall be loaded with corresion-inhibited fluid and left open at the surface or equipped with a pressure gauge to facilitate detection of tubing or packer leaks.