

UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
SUBMIT IN TRIPPLICATE
NM 071 (Other Instru
verse side)
Drawer DD
Artesia, NM 88210

Budget Bureau No. 1004-1.35
Expires August 31, 1985
5. LEASE DESIGNATION AND SERIAL
NM 0610
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

NOV 4 1985 SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

O. C. D.

ARTESIA, OFFICE AS WELL

OTHER

Water Injection

2. NAME OF OPERATOR

Kay Jay Oil Co. ✓

3. ADDRESS OF OPERATOR

P.O. Box 3565 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

660' FNL-1980' FEL-Sec.18-T16S-R30E

14. PERMIT NO.

15. ELEVATIONS (Show whether DE, RT, GR, etc.)

3761' GL

7. UNIT AGREEMENT NAME

SW Henshaw Premier Unit

8. FARM OR LEASE NAME

9. WELL NO.

5

10. FIELD AND POOL OR WILDCAT

West Henshaw Grayburg

11. SEC., T., R., M., OR BLK. AND
SURVEY OR ARMA

Section 18-T16S-R30E

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.) *

Propose to P & A subject waterflood injections well due to termination of water
injection as follows:

1. Set CIBP @ 2600' w/15 sx. cement on top of plug.
2. Spot 25 sx. cement plug 2050'-1800'. (Top of Queens).
3. Pressure test casing.
4. Perforate @ 1200' & spot 35 sx. cement plug. (100' inside & 100'
outside) Woc & tag plug.
5. Perforate @ 500' & spot 35 sx. cement plug. (100' inside & 100'
outside) WOC & tag plug.
6. Set 10 sx. surface plug.
7. Install dry hole marker & restore location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

7/19/85

(This space for Federal or State office use)

APPROVED BY

TITLE

AREA

DATE

11-1-85

CONDITIONS OF APPROVAL, IF ANY:

Subject to
Like Approval
by State

*See Instructions on Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the
United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.