

	TOPS
Г. Salt 493	
B. Salt 1315	
Yates 1690	
Glorieta	
Delaware	
Bone Sp	
Abo	
Wolfcamp	
Morrow	
Devonian	
Fusselman	
Other	

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up.
- Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0'- 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.

4

• Plugs to be tagged will be indicated.