

Page 2

Prognosis To Drill & Complete Square Lake Deep Unit No. 1

Completion:

1. Run temperature survey and Gamma Ray and collar log for correlation after WOC 10 hours.
2. Run tubing w/packer to PFED, pressure test casing to 1500 psi for 30 minutes after WOC 24 hours and displace water w/oil.
3. Pull tubing to 90' above pay zone, set packer and swab down fluid level.
4. Selectively perforate pay with through tubing gun.
5. Test zone natural.
6. Acidize, if necessary w/2500 gallons of 15% retarded acid.
7. Swab well in.

Completion:

1. Run tape drive survey and Gamma Ray and collar log for correlation after 1000 hours.
2. Run tubing wiper to 1000 feet pressure test casing to 1000 feet for 30 minutes after 1000 hours and displace water with oil.
3. Will tubing to 90' above pay zone, cut packer and screw down fluid level.
4. Relatively pressure pay with tubing tubing gun.
5. Test zone natural.
6. Addition, if necessary w/2000 gallons of 1% retarded acid.
7. Pump well in.