

Operator Ashorn O Inc.
Well NE Square Lake Prem. U+H 8
Unit M Section 2 Township 16 Range 31
API # 30-015-04785

TOPS

Yates 2360
T. Salt 1300
B. Salt 2300
Glorieta _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

← 60' Surface Plug

← Shoe Plug 326' - 426' - TAG

← 1300' - TAG

← 2406' - TAG

3338' ~ toe - calc

← 3950' - TAG

3964' - Perfs
3972

5 1/2"
4100'