

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN THE
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

IC-062483

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection	7. UNIT AGREEMENT NAME North Square Lake Premier Unit
2. NAME OF OPERATOR Shell Oil Company (Western Division) ✓	8. FARM OR LEASE NAME North Square Lake Premier Unit
3. ADDRESS OF OPERATOR P. O. Box 1509, Midland, Texas 79701	9. WELL NO. 21
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FWL & 660' FWL (Unit D), Section 8, T-16-S, R-31-E, BHPM Survey, Eddy County, New Mexico	10. FIELD AND POOL, OR WILDCAT North Square Lake GB/SA
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4025' DF
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 8, T-16-S, R-31-E, BHPM	12. COUNTY Eddy 13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☐
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) Convert to Water Injection	X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) _____	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Operation: Clean out and convert to water injection

1. Pull tubing.
2. Clean out to below lowest perforation (3304').
3. Run 2" plastic coated tubing w/packer. Circulate casing with fresh water containing 1#/bbl. sodium dichromate. Set packer at 3260'.
4. Set injection wellhead.

RECEIVED

JUL 25 1966

O. C. C.
ARTESIA, OFFICE

MOCC Order No. R-3016 & R-3017

RECEIVED
JUL 22 1966
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

Signed By **N. W. Harrison**
SIGNED **N. W. Harrison**

TITLE **Senior Exploitation Engineer** DATE **July 19, 1966**

(This space for Federal or State office use)

APPROVED BY **[Signature]** TITLE **ACTING DISTRICT ENGINEER**
CONDITIONS OF APPROVAL, IF ANY:

DATE **JUL 22 1966**

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of packing of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1965-O-665229

647-951

RECEIVED

1965 JUN 10

U.S. DEPT. OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FOR THE DIRECTOR