

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

**RECEIVED**  
 NEW MEXICO OIL CONSERVATION COMMISSION  
**MAR 20 1975**  
**O. C. C.**  
**ARTESIA, OFFICE**

Form C-100  
 Proposed  
 Application for Permit  
 to Drill or to Deepen or Plug Back to a Well

<input checked="" type="checkbox"/> <b>Oil</b> <input type="checkbox"/> <b>Gas</b> <input type="checkbox"/> <b>Other</b>	<b>B-2721</b>
--	---------------

**SUNDRY NOTICES AND REPORTS ON WELLS**  
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DEFENSE WELL. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Name of Operator <b>Kennedy Oil Company, Inc.</b>		2. State <b>State "C"</b>	
3. Address of Operator <b>Box 191 Artesia, New Mexico 88210</b>		4. Well No. <b>1</b>	
5. Location of Well UNIT LETTER <b>B</b> <b>660</b> <b>North</b> <b>1900</b> THE <b>East</b> LINE, SECTION <b>32</b> TOWNSHIP <b>16S</b> RANGE <b>11E</b>		6. Field No. (Well, or Wildcat) <b>Square Lake</b>	
7. Elevation (Show whether DF, RT, CR, etc.) <b>3923 RT</b>		8. County <b>Sully</b>	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPER. <input type="checkbox"/> CASING TEST AND CEMENT OR <input type="checkbox"/> OTHER <input type="checkbox"/>	CURRENT STATUS <input checked="" type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
---	--	--	--

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent data, including well logs, etc. See Rule 1103.)

**Plugged and abandoned as follows:**

**8/28/74** Set bridge plug @ 3136' and capped with 35' cement plug.  
**9/7/74** Out 5 1/2" casing at 1020' and pulled same  
 Ran tubing and placed heavy mud to 1070'.  
 Placed 100' cement plug at 5 1/2" pipe stub 1070'-970'.  
 Placed 100' cement plug @ top of salt 600'-700' mud between all plugs.  
 Placed surface plug, cleaned, cleared & leveled location  
 Placed regulation marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]*

**Pres.**

TITLE

**3/19/75**

APPROVED BY *[Signature]*

TITLE

CONDITIONS OF APPROVAL, IF ANY: