

State "FV" No. 1
Red Lake Queen, Grayburg, San Andres
Eddy County, New Mexico
Plug and Abandonment Procedure

1. Rig up service unit.
2. Spot a 150-foot, 40 sack Class "H" cement plug in the 7-inch casing
1300'-1450' across the top of the Queen formation (1402).
255x 350-450
3. Spot 10-sack plug to surface and weld on cap.
4. Erect plug and abandonment marker with location description as follows:

State "FV" No. 1
Unit N, Section 31, T-17-E, R-28-E

5. Clean up location and restore ground to contour.

Note: 1. Leave mud laden fluid between plugs.

2. Check and make sure the 7-inch annulus is not open at the surface. If open, it will be necessary to spot a 20 sack cement plug to surface in the annulus also.