

Operator Kersey & Co.
 Well Federal ASL 12.
 Unit 0 Section 11 Township 17s Range 28e
 API # 30-015 -- 10227

TOPS

es
 T. Salt 300'
 B. Salt 580'
 Glorieta
 Bone Sp.
 Abo
 Wolfcamp
 Morrow
 Devonian
 Fusselman
 Other

← 60' surface Plug

← 300' TAG

← 580' TAG

← 1484' TAG

= Perfs 1584' 94' 1616' - 28'

← 7" csg 1634' w/ 275 sx cement.

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

MS