

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

JUN - 8 '84

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator <b>Floyd Sherrell</b>		8. Farm or Lease Name <b>Floyd Sherrell</b>
3. Address of Operator <b>Route 1, Box 200, Artesia, New Mexico 88210</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>2080</b> FEET FROM THE <b>South</b> LINE AND <b>2200</b> FEET FROM <b>West</b> LINE, SECTION <b>32</b> TOWNSHIP <b>17 South</b> RANGE <b>26 East</b> NMPM.		10. Field and Pool, or Wildcat <b>Three Mile - San Andres</b>
15. Elevation (Show whether DF, RT, GR, etc.)		12. County <b>Eddy</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Run cement bond log.  
If possible, cut and pull 5-1/2" casing.  
Spot plug from 1550' - 1350' and tag.  
Spot stub plug 50' in and out.  
Spot shoe plug 50' in and out and tag.

*Handwritten:*  
STUB PLUG 50' in and out  
SHOE PLUG 50' in and out

*Handwritten:*  
Post ID-3  
9-14-84  
convert to water  
same well

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED G. C. Denton TITLE Agent DATE June 8, 1984

APPROVED BY M. A. Williams TITLE OIL AND GAS INSPECTOR DATE JUN - 8 1984

CONDITIONS OF APPROVAL, IF ANY: