

Operator Jenkins Bros. Drilling Co.  
Well Boling St. #2  
Unit I Section 9 Township 17S Range 28E  
API # 30-015-21787

TOPS

Notes \_\_\_\_\_  
A. Salt \_\_\_\_\_  
B. Salt \_\_\_\_\_  
Glorieta \_\_\_\_\_  
Bone Sp. \_\_\_\_\_  
Abo \_\_\_\_\_  
Wolfcamp \_\_\_\_\_  
Morrow \_\_\_\_\_  
Devonian \_\_\_\_\_  
Fusselman \_\_\_\_\_  
Other \_\_\_\_\_  
\_\_\_\_\_

← 60' Surface Plug

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

← plug 650' TAG

= Perfs. - 662' - 666'

← 4 1/2" csg 2705' w/ 175 sacks cement. Circ.