

COMPANY <i>Delmar W. Berry</i>		PROPERTY NAME <i>Quail State</i>		WELL NO. <i>1</i>
DATE <i>8-17-28</i>	LOCATION (ULSTR) <i>U + N</i>		FOOTAGE <i>990 FSL 1650 FWL</i>	
API NO.		POOL <i>Red Lake Q-C-5A</i>		

1. Spot a 50 SX plug @ 1538' woc Tag
2. Spot a 50 SX plug @ 670' Tag
3. Spot a 10 SX plug @ surface!
4. Set P+H marker
5. Cut anchors, clean + level location.

Mud shall be placed between plugs.

After

CASING RECORD:

7" @ 539' 8" hole 100 SX CLC

5 1/2" @ 1488' 6 1/2" hole 100 SX CLC