

7.

Proposed Plugging Procedure (continued)

6. Set cement plugs as follows:

40 sacks	4 1/2" stub	<i>and tag.</i>
40 sacks	4250'	
40 sacks	2300'	
40 sacks	1400'	<i>and tag</i>
40 sacks	850'	<i>400</i>

Hole to be loaded with 10#/gal mud laden fluid.

7. Set 10 sack cement plug at surface with dry hole marker.

5-1-80

Set Bridge Plug @ 7650 and 40 ft Cement on Top of Plug

5-5-80

Set 40 SX @ 6328 Tagged at 6138

Cut 4 1/2 @ 6250 + Pull

Set 40 SX @ 4250

Set 40 SX @ 2300

Set 40 SX @ 1400

5-6-80

Tag Plug @ 1282

Ad. J. B. B.