

Atlantic Richfield

H-33-17-28 Empire Abo Unit # 321

Set Surface

Hit Water Flo @ 538 Ft Approx 15 Bbls R Hr

TD @ 739 ft

11" Hole

8⁵/₈ Casing #24 LB K-55

Texas Pattern Guide Shoe

Baker Insert Float @ 699 ft

Lynnes Casing Packer @ 432 ft

Baker 2 Stage Tool @ 390 ft

1st Stage Cement 100 Sack Howco Thick Set

100 sack Class C 2% CC #6 Salt

Circulated 20 Sacks

2nd Stage 225 Sacks Class C 2% CC #6 Salt

Circulated 30 Sacks Cement

Started Job 1:00 Am Finished 9:00 Am

B.Y B.W Weaver