

Operator Beach Exploration  
 Well Red Lake Unit #14  
 Unit M Section 25 Township 16 Range 28  
 API # 30-015-23293

TOPS

A. Salt 340  
 B. Salt 575  
 Yates 585  
 Glorieta \_\_\_\_\_  
 Delaware \_\_\_\_\_  
 Bone Sp. \_\_\_\_\_  
 Abo \_\_\_\_\_  
 Wolfcamp \_\_\_\_\_  
 Morrow \_\_\_\_\_  
 Devonian \_\_\_\_\_  
 Fusselman \_\_\_\_\_  
 Other \_\_\_\_\_

← 60' plug in cement.

← Toc-290'

← Perf. squeeze 100' cent in cement  
 290-390' TAG

← 25 sk plug 575-925' TAG

← CTR 135' cent.

1575  
 1599  
 4 1/2"  
 1629'

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.