

Operator Beach Exploration Inc

Well Red Lake 4+ #24

Unit C7 Section 36 Township 14 Range 28

API # 30-015-23658

TOPS

Yates 750

T. Salt 290

B. Salt 685

Glorieta

Bone Sp.

Abo

Wolfcamp

Morrow

Devonian

Fusselman

Other

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

← 60' Surface Plug

8 5/8"  
318  
Circ  
← Shoe Plug 268' - 368' - Tag

← 700' - Tag

900' ——— TOC

← 1750' Tag

1778  
1824  
1815

4 1/2"  
1882'