

Operator Beach Exploration Inc

Well Ryan Fed #2

Unit H Section 14 Township 16 Range 29

API # 30-015-24131

TOPS

Yates 763

T. Salt 340

B. Salt 1000

Glorieta

Bone Sp.

Abo

Wolfcamp

Morrow

Devonian

Fusselman

Other

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

← 60' Surface Plug

85'
348'
Circ
2

← Shoe Plug 298' - 398' - TAG

500' ——— TOC

← 750' - TAG

← 1650' - TAG

1688 ——— Top Plug

5'2"
2300'