

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

SEP - 1 1993

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION / (505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650 FNL 4 230/FEL
Sec. 28-17S-25E

5. Lease Designation and Serial No.

NM-0219603

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Federal BZ #26

9. API Well No.

30-015-24604

10. Field and Pool, or Exploratory Area

Eagle Creek San Andres

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon well as follows:

1. Pull rods, pump and tubing.
2. Run 2-3/8" tubing to TD. Load hole with 10#/gallon brine containing 25#/bbl salt water gel.
3. Spot a 10 sack Class "C" plug from 1213-1069' (across perforations and 7" shoe). Pull tubing to 700' and circulate hole clean. WOC 4 hours and tag plug.
4. Spot a 10 sack Class "C" plug from 422-278' (10-3/4" shoe).
5. Spot a 10 sack Class "C" plug at surface.
6. Cut off wellhead and install regulation abandonment marker.

NOTIFY BLM (887-6544) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

14. I hereby certify that the foregoing is true and correct

Signed

Rusty Klein

Title Production Clerk

Date August 3, 1993

(This space for Federal office use)

Approved by

Conditions of approval, if any:

Title

Date

AUG 3 1993