

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

SNOW OIL AND GAS, INC.

3. Address and Telephone No.

P.O. BOX 1277 ANDREWS, TEXAS 79714

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

790' FSL AND 1174' FWL, SECTION 19, T-16-S, R-29-E

NM OIL CONS COMMISSION

Drawer DD

Artemis, NM 88210

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM89878

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

7 UP FEDERAL #1

9. API Well No.

30-015-25443

10. Field and Pool, or Exploratory Area

HIGHLONSOME QUEEN

11. County or Parish, State

EDDY COUNTY, NEW MEXICO

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐ Notice of Intent
☐ Subsequent Report
☒ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. 8-10-95 - NOTIFY PETER CHESTER OF ROSWELL BLM DISTRICT ON INTENT TO PLUG AND ABANDON.

2. 8-11-95 - MOVE IN RIG UP - UNITED OIL SERVICES RIG #4.

3. PULL OUT OF HOLE WITH PRODUCTION EQUIPMENT

4. RUN & SET 5 1/2 CIBP 1735' TIH W/ TBG TAG PLUG.

5. CIRC HOLE W/ 9.5 MUD SPOT 20 SX "C" NEAT ON CIBP.

6. PULL TBG TO 346' SPOT 25 SX "C" NEAT.

7. PULL TO 60' INSTALL 10 SX "C" TO SURFACE.

8. CUT OFF WELLHEAD CMT TO SURFACE. VISUAL VERIFICATION. INSTALL DRY HOLE MARKER VALVE
BACK FILL PIT & CELLAR. RIG DOWN SERVICE UNIT.

9. REMOVE ALL PRODUCTION EQUIPMENT AND MATERIAL FROM SURFACE LOCATION. RIG UP SURFACE
LOCATIONS. RECONTOUR.

10. RESEED AS PER AREA SPECIFICATIONS.

14. I hereby certify that the foregoing is true and correct

Signed

Paul W. Snow

Title PRODUCTION ENGINEER

Date 9/15/95

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any: