

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

JUN - 1 1992

O. C. D.
OFFICE

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.
N.M.81260

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Max Federal

9. API Well No.

1

10. Field and Pool, or Exploratory Area

Henshaw Queen GBG San

11. County or Parish, State
Andres
Eddy County, New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Meadco Properties

3. Address and Telephone No.

P. O. Box 2236, Midland, Texas 79702, 915-682-5671

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

2150 F.N.L. & 1875 F.E.L., Section 13, T-16-S R-30-E

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Inform B.L.M. 24 hours prior to plugging
2. Pull tubing. SPOT 35' OF CEMENT ON TOP CIBP AT 3685' - TAG PLUG.
3. Set CIBP with wireline at 2600 ft. cap with 35' cement using bailer
4. Run tubing, circ. well with 9# mud.
5. Pump cement plug from 483'-383' - TAG PLUG.
6. Pump 75' cement plug from surface - 75'
7. Cut off wellhead and install dry hole marker
8. Restore surface as per Federal regulations

14. I hereby certify that the foregoing is true and correct

Signed M. R. Kelly

Title Operations Foreman

Date 5/18/92

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date 5/29/92