

Page 2

18. Flow test well and stimulate if necessary.
19. RDPU. Clean and level location.
20. Run C.A.O.F.P. and pressure build up.
21. Connect surface equipment.