

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs NM 88240

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, New Mexico 87505

DISTRICT II  
811 South First, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd, Aztec, NM 87410

WELL API NO.  
30-015-02856

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
B-514

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS).

1. Type Of Well:  
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator  
MACK ENERGY CORPORATION

3. Address of Operator  
P.O. Box 960, Artesia, NM 88211-0960 (505) 748-1288

4. Well Location  
Unit Letter D : 1317 Feet From The North Line and 1317 Feet From The West Line  
Section 28 Township 17S Range 29E NMPM Eddy, NM County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
3586

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 2040' 100' above 5" liner with 35' cement plug.

2. Spot 100' plug from 695-595' tag 2. Perforate 6 5/8" csg @ 842'. Squeeze 100' cement Plug inside & outside 6 5/8" csg. TAG

3. Perforate 300' squeeze 100' plug in/out top salt. TAG

4. Spot 60' surface plug.

5. Install dry hole marker.

\* Brine gel between all cement Plugs.

\* Notify N.M.O.C.D. to witness Plugging Operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Crissa D. Carter TITLE Production Analyst DATE 5/15/2000

TYPE OR PRINT NAME

Crissa D. Carter

TELEPHONE NO. (505)748-1288

(This space for State Use)

APPROVED BY Mrs. Stillfield TITLE Field Rep. II DATE 5/15/2000

CONDITIONS OF APPROVAL, IF ANY

