

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN
(Other inst
verse side)

PLICATE
ons on re

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 028480 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection Well

2. NAME OF OPERATOR

Continental Oil Company

3. ADDRESS OF OPERATOR

Box 460, Hobbs, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1650' FNL & 330' FEL of Section 7- T-17,
R-29, Eddy County, New Mexico, NMPM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3658 GR

7. UNIT AGREEMENT NAME

Cave Pool

8. FARM OR LEASE NAME

Cave Pool Unit

9. WELL NO.

53

10. FIELD AND POOL, OR WILDCAT
Cave Pool Unit Field
Cave Pool

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 7- T-17- R-29

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Convert Water Injection ☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to convert subject well to water injection by using the following procedures:

1. Run 2 3/8" tubing in hole and tag bottom.
2. Pull tubing and re-run with 7" packer set at 2000'
3. Fill casing with water and pressure up to 2000# for 15 minutes.
4. Pull tubing
5. Install injection head

Rec'd
JAN 4 1965

18. I hereby certify that the foregoing is true and correct

SIGNED SIGNED ROBERT CAULT III

TITLE Staff Supervisor

DATE 12-29-64

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

USGS-5, Dec-2, Partners - 11

*See Instructions on Reverse Side

APPROVED
DEC 31 1964
R. L. BELMONT
ACTING DISTRICT ENGINEER