

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

PERMIT IN TRIPLICATE
(ORIGINAL TO BE FILED IN REVERSE SIDE)

Form approved
Revised to meet No. 42 11424

5. LEASE IDENTIFICATION AND SERIAL NO.

LC 024480 (1)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDAY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water injection well	7. UNIT AGREEMENT NAME Cave Pool
2. NAME OF OPERATOR Continental Oil Company	8. FARM OR LEASE NAME Cave Pool Unit
3. ADDRESS OF OPERATOR Box 460 Hobbs, New Mexico	9. WELL NO. 93
4. LOCATION OF WELL (Report location clearly and in accordance with any State Requirements. See also space 17 below.) At surface 1650' ENL & 330' EEL of Section 7- T-17, R-29, Eddy County, New Mexico, NMPM	10. FIELD AND POOL, OR WILDCAT Cave Pool Unit Field
14. PERMIT NO.	11. SEC., T., R., OR BLM. AND SURVEY OR AREA Sec. 7, T-17, R-29
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3658 GR	12. COUNTY OR PARISH, THE STATE Eddy N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☐	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(other) Convert to Water Injection ☒	
(Other) ☐		(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The subject well was converted to water injection using the following procedure:

1. Run 2 3/8" tubing in hole & tagged bottom.
2. Pulled tubing and re-ran with 7" packer set at 2000'
3. Filled casing with water and pressured up to 2000# for 15 minutes.
4. Pulled tubing
5. Installed injection head.

Work performed 12-3-64. The well is now ready for water injection.

APPROVED
DEC 1 1964
DISTRICT ENGINEER

I hereby certify that the foregoing is true and correct
TITLE Staff Supervisor DATE 12-15-64

APPROVED BY _____ TITLE _____ DATE _____

USGS -5, NMOC- 2, Partners -11

*See Instructions on Reverse Side